

## DIGITAL DISPLAY COMPRESSION TESTING MACHINE MODEL NO – SL-CC-037, MAKE – LABTEK, ORIGIN – INDIA



The Digital Compression Testing Machine has been designed to meet the need for a simple, economic and reliable means to test concrete for its compressive strength. The Digital Indicator incorporates a 4-Digits display calibrated in Kilo Newton (KN) and preset to maximum load capacity fitted with micro switches to switch-off the motor when the load approaches the maximum capacity of the gauge, avoiding any over loading