

IMPACT TESTING MACHINE MAKE – LABTEK, ORIGIN – INDIA



This Pendulum impact Tester is designed for conducting CHARPY, IZOD AND IMPACT Test.
The test Method confirm to IS: 1973, and IS 1499-1977, and BS: 131 Part 2 & 3-1972 IS:
1598-1977, BS: 131 Part I- 1972

The impact energy absorbed by the specimen during rupture is measured as the difference between the height of drop before rupture and the height of rise after rupture of the test specimen and is read on the dial scale.