

INFRARED MOISTURE METER

MODEL NO – SL-GT-025, MAKE – LABTEK, ORIGIN – INDIA



ASTM D 4944 AASHTO T 217

This moisture meter has been designed for rapid and accurate determination of the moisture content of a wide variety of materials. It is torsion wire instruments, the torque being applied to one end of the wire by means of a calibrated drum to balance the loss of weight as the test sample dries under infrared radiation. The speed of drying (about 30 min) thus obtained, combined with the frictionless balancing system gives the result as accurate as those obtained by standard oven drying method.