

SUPER LIGHT MAKE – LABTEK, ORIGIN – INDIA



1. Reliable microcontroller based design
2. Brilliant 55 Watt halogen beam illuminates target at 350 meters
3. Selectable direct, dimmer, timer and flasher functions
4. Over 60 minutes of constant use at full light
5. Up to 5 hours of use with dimmed light
6. Rugged, weather resistant, molded ABS housing
7. Reliable rotary switch for easy selection of all functions
8. Easy-to-carry with molded handle and shoulder strap
9. Uses internal 12V / 7Ah sealed lead-acid battery
10. Internal SMPS battery charger for 90 to 270 Volt operation
11. Low battery warning indicates exhausted battery
12. Automatic low-voltage cut-off prevents deep discharge
13. Emergency operation is allowed even during automatic cut-off
14. High reliability MOSFET for solid state switching