

THREE CYLINDER FOUR STROKE PETROL ENGINE TEST RIG WITH MORSE TEST

MAKE – LABTEK, ORIGIN – INDIA



DESCRIPTION

The setup consists of three cylinder, four stroke, petrol engine connected to dynamometer for engine loading. The setup has stand-alone type independent panel box consisting of air box, fuel tank, manometer, fuel measuring unit. Engine jacket cooling water inlet, outlet and calorimeter temperature is displayed on temperature indicator. Flowmeters are provided for cooling water and calorimeter flow measurement. Provision is also made for conducting Morse test

B-3A, Shiv Shakti Complex, East Vinod Nagar, 1st Floor, New Delhi - 110 091

Phone : 011-65708108, 65808108 Mobile No : 09971077233, 09811888915

E-mail: info@labtekindia.com, Web: www.labtekindia.com