

Carpenter Workbench

MODEL NO – SL- 3020 MAKE – LABTEK, ORIGIN – INDIA



Double sided carpenter's work bench to accommodate 2 trainees, heavy construction of selected timbers, tops of selected knot free beech, tool well, nylon bench stops with mortices cut in bench tops at appropriate places to accept them, adjustable 2 side and 2 end vices of selected knot free beech with steel spindles, turned hardwood vice handles, tops surface treated with cellulose varnish, bench prefabricated assemblies at training centre, standard equipment 2 side vices, 2 end vices and bench stops supplied. Length: 1650 mm, Height: 800 mm, Thickness of top: 110 mm