

HYDRAULIC JACKS

MODEL NO – SL-CC-116, MAKE – LABTEK, ORIGIN – INDIA



Hydraulic Jacks have multipurpose utility, i.e. application of loads while engaged in field investigation, determination of load carrying capacity of piles in the field, tensioning of wires in pre-stressed structures, loading of members of any structure for deformation characteristics etc. The jacks are supplied complete with manually operated pumping units fitted with bourdon tube type load gauge and high pressure flexible hose pipe. All the jacks have a piston travel of 50 mm and jacks upto 1000 kN capacity are provided with retraction springs.

B-3A, Shiv Shakti Complex, East Vinod Nagar, 1st Floor, New Delhi - 110 091

Phone : 011-65708108, 65808108 Mobile No : 09971077233, 09811888915

E-mail: info@labtekindia.com, Web: www.labtekindia.com