

PROVING RINGS 2000KN MODEL NO – SL-CC-048 TO 060, MAKE – LABTEK, ORIGIN – INDIA



Specification: The Proving Rings are made of special steel, carefully forged to provide high and stable accuracy, dependability and repeatability. The dial gauge and anvil are mounted on U-brackets clamped to the ring body by set screws. The indicator has a sensitivity of 0.002mm/ div and the deflection is directly proportional to the applied load. The rings are supplied complete with dial gauge and Works Calibration Chart, individually packed in polished wooden boxes. NPL (India) / NCCBM Calibration Certificates can also be arranged for any proving ring at an additional cost. Separate Pair of Loading Pads are provided to suit each proving ring.

B-3A, Shiv Shakti Complex, East Vinod Nagar, 1st Floor, New Delhi - 110 091

Phone : 011-65708108, 65808108 Mobile No : 09971077233, 09811888915

E-mail: info@labtekindia.com, Web: www.labtekindia.com