

SAND POURING CYLINDER

MODEL NO – SL-GT-026, MAKE – LABTEK, ORIGIN – INDIA



As Per IS 2720 (P-XXVIII) BS 1377-9

Specification :

The soil testing equipment is used for determination of the dry density of compact, fine, medium grained soils and for layers not exceeding 50cm thickness. A circular hole is dug into the ground, all the soil from within it collected, weighed and dried, and the hole back filled with a standard uniform sand or fine gravel, poured from a calibrated container for calculating the volume of hole. The complete apparatus consists of a Sand Pouring Cylinder fitted with Conical funnel and Shutter, Cylindrical Calibration Container, and a Metal tray with a central hole.

B-3A, Shiv Shakti Complex, East Vinod Nagar, 1st Floor, New Delhi - 110 091

Phone : 011-65708108, 65808108 Mobile No : 09971077233, 09811888915

E-mail: info@labtekindia.com, Web: www.labtekindia.com