

ULTRASONIC FLAW DETECTOR MAKE – LABTEK, ORIGIN – INDIA



This unit has a variable square wave pulsar to optimize the performance of transducers. Probe sensitivity is increased by pulse width variation.

- 1). Bench mounted unit.
- 2). Bright electro-luminescent display.
- 3). Frequency range 5 bands 1MHz to 35 MHz
- 4). Test modes pulse echo and transmit/receive.
- 5). Update rate 60Hz.
- 6). 5 Measurement modes.
- 7). Selectable damping.
- 8). Continuously variable probe zero.

B-3A, Shiv Shakti Complex, East Vinod Nagar, 1st Floor, New Delhi - 110 091

Phone : 011-65708108, 65808108 Mobile No : 09971077233, 09811888915

E-mail: info@labtekindia.com, Web: www.labtekindia.com