

CORE CUTTING/ DRILLING MACHINE (DIESEL ENGINE DRIVEN)

MODEL NO SL -BT -024, MAKE - LABTEK, ORIGIN - INDIA



Suitable to cut/drill cores of concrete, rocks, stones, tiles or the similar materials. The machine is suitable for core samples of size upto 150 mm diameter with the help of thin walled diamond bits which are at extra cost. The machine has sturdy base with pillar support in which rack and pinion is provided for adjustment in height and penetration assembly. The leveling screws are provided at the base. For gripping the sample in position suitable grips are provided. A suitable diesel engine is fitted in the machine with cooling arrangement with water. The base frame is also fitted with wheels for ease of transportation.